


PROFESSIONAL AIR STRIPPING TOOL



Index No.	Part No.	Description	Q'ty	Index No.	Part No.	Description	Q'ty
1	513-001	Eraser Wheel	1	24	216-037	Seal Lump	1
2	513-002-B	Connect Shaft	1	25	217F-025	Motor Housing	1
3	512-041	Nut	1	26	00-41121	O-Ring	2
4	512-004	Housing Cover	1	27	218F-026	Bushing	1
5	00-2330	Ball Bearing	1	28	00-41133	O-Ring	1
6	513-016-B	Cage	1	29	00-41132	O-Ring	1
7	00-4135	O-Ring	1	30	216F-027	Valve Stem	1
8	513-015	Idler Gear Housing	1	31	218F-029	Spring	1
9	513-017	Idler Gear	2	32	551F-038	Regulator	1
10	00-3405	Pin	2	33	00-4102	O-Ring	1
11	00-2306	Ball Bearing	1	34	00-41134	O-Ring	1
12	512-018	Spacer	1	35	551F-030	Valve Plug	1
13	00-2314	Ball Bearing	1	36	511F-024	Throttle Lever	1
14	00-3325	Spring Pin	2	37	00-3341	Spring Pin	1
15	511-019	Front End Plate	1	38	216-038B	Muffler	1
16	00-3328	Spring Pin	1	39	00-4151	O-Ring	1
17	511-006	Spacer	1	40	217-042	Hose Adapter	1
18	216-021	Rotor Blade	4	41	217-034A	Air Inlet (1/4" PF)	1
19	513-020	Rotor	1		217-034B	Air Inlet (1/4" PT)	
20	511-022	Cylinder	1		217-034C	Air Inlet (1/4" NPT)	
21	218F-023	Rear End Plate	1	42	305C-022	Bushing	1
22	00-2323	Ball Bearing	1	43	513-007	Spanner	1
23C	218F-045-C	Rear Gasket	1				